

Job Aid: Steps for Best Practice Garbing for Sterile-to-Sterile Nonhazardous Compounding with Sink on Clean Side of Anteroom


- Change into scrubs and facility-dedicated shoes
- Use restroom; remove makeup, jewelry, and extra clothing; tie up hair
- Clean personal glasses with EPA-registered one-step bactericidal disinfectant cleaner wipe for frames and lens cleaner for lenses; enter the anteroom




















under chin; no gaps; beard cover over mask if goatee

- Perform hand hygiene, including a 30-second lather to the elbows, after
- Dry hands with low-lint wipes
- Don gown (do not put thumb loops in place)

using nail pick on wet, lathered hands

10. Enter the buffer room







- 11. Obtain sterile gloves; remove from the outer package at empty, clean counter surface
- 12. Apply alcohol-based hand rub to nails, hands, and wrists
- 13. When dry, put thumb loops in place and don sterile gloves
- 14. Sanitize gloves with sterile IPA (unless initial GFT scheduled)

