

Job Aid: Steps for Best Practice Garbing for Sterile-to-Sterile Nonhazardous Compounding with Sink on Dirty Side of Anteroom

Before entering anteroom

- Change into scrubs and facility-dedicated shoes
- Use restroom; remove make-up, jewelry, and extra clothing; tie up hair
- Clean personal glasses with EPA-registered one-step bactericidal disinfectant cleaner wipe for frames and lens cleaner for lenses; enter the anteroom.







Dirty side anteroom

Don a face mask with folds down on outside, bend nose bar, pull down under chin; no gaps; beard cover over mask if goatee

- Don head cover (bouffant cap) over ears and a hood if full beard, hijab, or other headdress or if hair not contained in bouffant; if goatee-type beard, beard cover over face mask
- Perform hand hygiene, including a 30-second lather to the elbows, after using nail pick on wet, lathered hands







Clean side anteroom

- Don shoe covers one at a time, stepping over LOD entering clean side of anteroom
- Apply alcohol-based hand rub to nails, hands, and wrists
- Don gown (do not put thumb loops in place)
- 10. Enter the buffer room









- Obtain sterile gloves; remove from outer package at empty, clean counter surface
- 12. Apply alcohol-based hand rub to nails, hands, and wrists
- 13. When dry, put thumb loops in place and don sterile gloves
- 14. Sanitize gloves with sterile IPA (unless initial GFT scheduled)



