




<p>Before entering anteroom</p>	<ol style="list-style-type: none"> 1. Change into scrubs and facility-dedicated shoes 2. Use restroom; remove makeup, jewelry, and extra clothing; tie up hair 3. Clean personal glasses with EPA-registered one-step bactericidal disinfectant cleaner wipe for frames and lens cleaner for lenses 4. Perform hand hygiene, including a 30-second lather to the elbows, after using nail pick on wet, lathered hands 	
<p>Dirty side anteroom</p>	<ol style="list-style-type: none"> 5. Enter anteroom 6. Don face mask with folds down on outside, bend nose bar, pull down under chin; no gaps 7. Don head cover (bouffant cap) over ears <i>and</i> hood if full beard, hijab, or other headdress or if hair not contained by bouffant; don beard cover for goatee-type beards 8. Don shoe covers one at a time, stepping over LOD entering clean side the anteroom 	
<p>Clean side anteroom</p>	<ol style="list-style-type: none"> 9. Apply alcohol-based hand rub to nails, hands, and wrists 10. Don gown (do not put thumb loops in place) 11. Enter the buffer room 	
<p>ISO 7 buffer room</p>	<ol style="list-style-type: none"> 12. Obtain sterile gloves; remove from outer package at empty, clean counter surface 13. Apply alcohol-based hand rub to nails, hands, and wrists 14. When dry, put thumb loops in place and don sterile gloves 15. Sanitize gloves with sterile IPA (unless initial GFT scheduled) 	